



SGR-12 ELECTRIC DRUM MAGAZINE (3100BBS) INSTRUCTION MANUAL

Cyma No.:M275


1. Use your finger to push down the movable part shown in the diagram, then rotate it in the direction of the arrow and remove the transparent cover.



2. Open the transparent cover, find the charging port of the power supply (located in the lower position), connect the 5V/1-2A power adapter with the charging cable, align it with the charging port, and fully charge the battery before use.



3. Pull the BBS compartment as indicated by the arrow in the diagram until you hear a "click" sound, then load the BBS into the bullet compartment.



4. a. Manual loading: Press the button at the bottom of the drum magazine, and the BBs will continuously load the full trajectory. Install the appropriate accessories onto the drum magazine, Press and hold button, and the press the firing device to continuously loading and shooting.
b. Voice controlled loading: Setting the voice controlled loading system. Without pressing the button below the drum magazine, when the loading is not smooth, the voice control system will continue to load until the internal BBs are used up or the firing stops.
c. Keep pressing the button to turn on the drum magazine ; press the button three times in a row within 5 seconds can turn it off. When the drum magazine is already turned on, Keep pressing the button to keep it loading; If there is no movement for 1 minute, it will enter sleep mode and shut down.
d. When the light flashes at the charging interface, it indicates that the battery is running low and the BBs loading supply will stop. At this time, it is necessary to charge the drum magazine. When the indicator light at the interface does not flash during charging, it indicates that charging has been completed.

