

Ring Cup Airsoft Grenade

Ring Cup airsoft grenades work with ring capsules (size 8), which can be purchased at AirsoftPro or any toy store without a licence. They are also easily available online. The grenade does not fire any projectiles. It uses the sound and light emitted when the capsules are fired.

It is an impact grenade, where upon impact, a striker is released, which strikes the capsule holder and all capsules are fired at once – sound and light signals.

Due to the nature of the impact, the softer the surface on which the grenade lands, the greater the chance that it will not fire. It may not fire in tall grass or sand – the impact is muffled and insufficient.

Important settings

Pay attention to the markings on the top of the striker and striker holder (top part). The arrows must point towards each other – this ensures that the spring is in the correct position. Otherwise, the striker would not stay in place and could not be secured!

It should not be twisted or turned. The position will not change during normal use, but it is advisable to check the position from time to time.



Grenade loading procedure

1. Unscrew the upper part with the striker from the grenade body.
2. Insert (press) the capsule ring into the capsule holder and insert it into the grenade body so that the "TOP" inscription on the capsule holder points upwards (towards the striker).
3. Set the upper part with the striker to the "F" position (FIRE / Unlocked - black arrow pointing to the letter "F") using the rotating ring. Press the spring with the striker, hold it, and set the ring to the "S" position (SAFE - black arrow pointing to the letter "S").
4. Screw the upper part with the striker into the grenade body. The grenade is now loaded and secured, ready for use.
5. Before throwing, the ring must be switched to the "F" position and the grenade thrown.

Do not use empty or without a capsule holder, as this could damage the striker and capsule holder!

Recommendation

Before playing, it is advisable to prepare several rings of capsules in the capsule holder, which can be stored in a small pocket so that the grenade can be quickly reloaded during play.