

# **TITAN** Digital Charger

1. Connect power cable to charger and wall.
2. Connect white battery balance plug

The digital display is capable of showing stats both while charging and also on the go without a power cable. The first stat shown is “**All**” followed by a voltage reading. This reads how much voltage is left in the pack, and the graphs on the front of the charger can be used to check. After the “**All**” voltage is displayed, the charger will cycle through each individual cell and display each cell’s voltage.

When charging is complete, device will display “**FUL**” & beep.

## **Error Codes:**

If charger detects and error, charging will stop. Display shows the error code, and the charger beeps. Reconnect the power cable to restore the charger.

- Er0-Er8 Self safety check can not pass
- Er2 Input voltage or power is out of range
- Er9 One or more cells of the battery is bad

For all warranty inquiries, please email Titan directly at  
**[contact@gettitanpower.com](mailto:contact@gettitanpower.com)**